

Critical Guidance Protocol for PP Rigid Containers

Document number – PP-CG-01

Revision date - September 9, 2024

Introduction – Scope, significance and use

This is a comprehensive laboratory scale evaluation, or protocol, that can be used to assess the compatibility of PP Rigid container packaging innovations with reclamation systems sourcing post-consumer material.

PP rigid containers typically consist of natural and color homopolymer, copolymer, or random copolymer. Containers are typically in forms of tubs, lids, bottles, and other molded/shaped/formed articles. This test can be used to evaluate the impact of PP rigid container packaging components. Examples including multi-layer constructions, coatings, additives, printing, labels, adhesives, new PP resin controls, new innovative PP resins, multi-material compositions, lids, dispensers and closures.

In APR Processing Practices and Test Protocols, the term "article" is used to mean the package submitted for testing (except in the special case where a resin pellet is tested and is referred to simply as "resin pellet"). The article incorporates the "innovation" or "design feature" which requires test data for an APR recyclability classification. Generally, an "innovation" is a modification or addition to a package construction that provides functional improvements and a "design feature" is an element of design geared toward ease of consumer use or marketing benefit. However, in APR documents the two terms may be used interchangeably.

Data developed by an independent third-party laboratory following this protocol can be used in petitions for APR's Critical Guidance Recognition. Petitions require data for a control material, and for the innovation articles blended with extruded articles.

Before Critical Guidance Protocol test results can be submitted to APR for consideration of guidance recognition, all pre-requisite tests, including sortation potential protocols and degradable additives testing, must be passed and such evidence should be presented with any guidance applications. To determine when pre-requisite testing is needed, please refer to the <u>APR PP Rigid Design® Guide</u> and following test protocols and resources:

For metal and metal containing:

- <u>RES-SORT-03b Metal Sorting Resource</u>
- <u>SORT-S-03 Metal Sortation Protocol</u>

For items less than 5 cm in 2 dimensions:

- <u>RES-SORT-02 Size Sortation Resource</u>
- SORT-S-02 Size Sortation Protocol
- SORT-P-00 Compression Practices

For dark colors (see definition in Design® Guide)

- <u>RES-SORT-01 NIR Sorting Resource</u>
- <u>SORT-S-01 NIR Sortation Protocol</u>



For materials that employ time dependent behavior or environmental exposure where appearance or physical properties are expected to change over time:

<u>APR Position Paper - Degradable Additives</u>

This list is not inclusive. The Critical Guidance Protocol is not appropriate for package constructions that are not in alignment with the APR Design[®] Guide for Plastics Recycling text in cases where further testing is specified in the relevant Design[®] Guide section.

Disclaimer: This document has been prepared by the Association of Plastic Recyclers as a service to the plastic industry to promote the most efficient use of the nation's plastic recycling infrastructure and to enhance the quality and quantity of recycled postconsumer plastic. The information in this document is offered without warranty of any kind, either expressed or implied, including WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, which are expressly disclaimed. APR and its members accept no responsibility for any harm or damages arising from the use of or reliance upon this information by any party. Participation in the Recognition Program is purely voluntary and does not guarantee compliance with any U.S. law or regulation or that a package or plastic article incorporating the innovation is recyclable or will be recycled.

The results of testing using APR's Critical Guidance Test Protocols along with a Critical Guidance Technical Review are intended to qualify a company's innovation for APR's Critical Guidance Recognition only. The complete testing protocol process requires a review of the test results by a Technical Review Team convened by APR. If test results are not reviewed by an APR Technical Review Team, no APR recognition is possible. APR does not give permission for its name to be used to claim, or to imply in any way, that APR has recognized or approved the design feature or innovation that was tested when APR has not reviewed the test results

The APR's Critical Guidance Recognition does not convey any consideration by any other organization nor guarantee recognition by any other organization. APR does not share submitted data with any other organizations. Whether a company achieves APR recognition is solely dependent upon the results of an APR review of test data. If APR intellectual property is to be used as documentation or justification toward any other organization's evaluation or recognition, no claim of APR approval or recognition may be made under such circumstances without the express written permission of APR. When data are used by other organizations outside of APR's recognition programs, in the absence of a licensing agreement with such organizations, the APR does not give permission for its name to be used to claim, or to imply in any way, that APR has recognized or approved the design feature or innovation that was tested. APR does not recommend, advocate, or influence any other organization's decision making in this regard.

Although test data generated by a company is the property of that company and may be used for other purposes besides APR Critical Guidance Recognition, the test protocols are the property of APR and APR



requires that they be used as written in their entirety. It should also be noted that partial test results that may under-report negative impacts from an innovation or design feature could misrepresent APR's intention or position and will be called out by APR when these incidents come to APR's attention.

3 of 13



Method Summary

This Critical Guidance protocol provides two pathways for testing PP resins and articles with flow diagrams found on pages 8 and 9 for articles that employ multi-layer constructions, coatings, additives, printing, labels, adhesives, new HDPE resin controls, new innovative HDPE resins, multi-material compositions, lids, dispensers and closures. Controls are comprised of similar articles made solely with a control PP resin without the innovation. Reference document <u>APR Polyolefin Standard Laboratory Processing Practices</u>, O-P-00 through O-P-07 for complete details.

<u>Path 1</u> – Path 1 is utilized for complete PP packages in the form of bottles, jars and jugs that include the innovation being tested. A flow diagram for Path 1, on page 8 illustrates that these articles are separately processed through these steps:

- Granulation
- Commercial Basic Wash and drying
 - o Small 100g caustic wash required when labels with adhesives or printing are present
- Elutriation
- Blends created from the processed materials. APR Critical Guidance protocols require blends of 50% control and 50% innovation to be compared with 100% control material. Optional blends can be used if desired by the investigator at 75% control and 25% innovation blend.
- Blends dried, extruded and pelletized
- Pellets subjected to testing and evaluation
- Pelletized material is injection molded into ASTM test parts for mechanical properties evaluation

<u>Path 2</u> - Path 2 is utilized for testing resins and resin blends that incorporate the innovation being tested but have not been converted into package form. A flow diagram for Path 2 on page 9 illustrates that these articles are separately processed through these steps:

- Control and test dry blends processed for a melt history to represent the initial production heat history.
- Blends created from the processed materials. APR Critical Guidance protocols require blends of 50% control and 50% innovation to be compared with 100% control material. Optional blends can be used if desired by the investigator at 75% control and 25% innovation blend.
- Blends dried, extruded and pelletized
- Pellets subjected to testing and evaluation
- Pelletized material is injection molded into ASTM test parts for mechanical properties evaluation



Reference Documents

The following documents are referenced in this Critical Guidance Protocol:

APR Polyolefin Standard Laboratory Processing Practices, O-P-01 through O-P-07

APR Screening Test Methods:

Polyolefin Packaging Article Sink or Float Evaluation, O-S-01

ASTM Pellet Test Methods:

ASTM D3418 Transition Temperatures and Enthalpies of Fusion and Crystallization of Polymers by Differential Scanning Calorimetry ASTM D1238 Melt Flow Rates of Thermoplastics by Extrusion Plastometer ASTM D792 Density and Specific Gravity (Relative Density) of Plastics by Displacement ASTM D1505 Density of Plastics by the Density-Gradient Technique ASTM D5630 Ash Content in Plastics ASTM D6980 Determination of Moisture in Plastics by Loss in Weight ASTM D1895 Apparent Density, Bulk Factor, and Pourability of Plastic Materials ASTM D6290 Color Determination of Plastic Pellets

ASTM Part Test Methods:

ASTM D638 Tensile Properties of Plastics ASTM D256 Determining the Izod Pendulum Impact Resistance of Plastics ASTM D790 Flexural Properties of Unreinforced and Reinforced Plastics and Electrical Insulating Materials

Optional ASTM Test Methods:

ASTM D1693 Environmental Stress-Cracking of Ethylene Plastics





Method Steps for Extrusion Blends and Injection Molding Evaluation

Safety Statement: APR Test and Practice documents do NOT CLAIM TO ADDRESS ALL OF THE SAFETY ISSUES, IF ANY, ASSOCIATED WITH THEIR USE. These Tests and Practices may require the use of electrically powered equipment, heated equipment and molten polymers, rotating motors and drive assemblies, hydraulic powered equipment, high pressure air, and laboratory chemicals. IT IS THE RESPONSIBILITY OF THE USER TO ESTABLISH AND FOLLOW APPROPRIATE SAFETY AND HEALTH PROCEDURES WHEN UNDERTAKING THESE TESTS AND PRACTICES THAT COMPLY WITH APPLICABLE FEDERAL, STATE AND LOCAL REGULATORY REQUIREMENTS. APR and its members accept no responsibility for any harm or damages arising from the use of or reliance of these Tests and Practice documents by any party.

Path 1 Method Steps

The following steps are taken to prepare samples for evaluation; these steps are illustrated in the flow diagram labeled Path 1, and details of each step are presented in the <u>APR Polyolefin Standard Laboratory Processing</u> <u>Practices</u>, O-P-01 through O-P-07 (included in document O-P-00). The amount of material will depend upon the equipment and scale used in each laboratory.

- 1. Obtain control and test article to use in the evaluation for Path 1. For a list of acceptable control resins, refer to Practice O-P-01.
- 2. For each of the test and control articles for Path 1, separately:
 - a. Granulate articles
 - b. Sink-float the control and test materials per the Screening Test O-S-01
 - c. Commercial Basic Wash and drying
 - i. Small caustic wash required when labels or printing is present
 - d. Elutriation of granulated material
- 3. Prepare the following required blends:
 - a. 100% processed control Sample A
 - b. 50/50 processed control and innovation Sample B
 - c. Any optional blends chosen by the investigator, for example: 75/25 processed control and innovation Sample C
- 4. Extrude blends and melt filter to create the samples: A pellets, B pellets and optional C pellets.
 - a. Extruded pellets to be evaluated for DSC, melt flow, density, ash content, moisture content, bulk density, FTIR, and color.
- 5. Injection mold part for mechanical evaluation of each blend

Injection molded part to be evaluated for flexural modulus, tensile strength, notched Izod and optional ESCR.



Path 2 Method Steps

If the form submitted for testing is resin instead of containers, Path 1 method steps 1 and 2 are unnecessary. Steps 3, 4, and 5 for resin samples are illustrated in the flow diagram labeled Path 2.

7 of 13

Details of each step are presented in the *APR Polyolefin Standard Laboratory Processing Practices*, O-P-01 through O-P-07 (included in document O-P-00).

The amount of material will depend upon the equipment and scale used in each laboratory.





Measurements, Report and Guidance Values <u>Path 1 - Incoming Flake Analysis</u>

Property	Method	APR Guidance Preferred values	Additional Guidance
	·	Required values	
Sink-float	O-S-01	100% Floatability for Olefin material	Any non-PO labels, closures, layers, attachments, or other materials must either sink in water and be removed or must be compatible with PP. It is unacceptable for a non-PP material to stick to or otherwise not separate from the PP substrate and cause the PP to sink, resulting in yield loss, or stay with the PP and contaminate the PP.

Path 2 - 1st Melt History Extruded Pellet

Property	Method	APR Guidance Preferred values	Additional Guidance	
Optional Values				
Screen Pack Pressure Build	Practice O-P-06	Record and Report	No guidance, first step only for melt history	

Path 1 and 2 - Extruded Pellet Evaluation

Property	Method	APR Guidance Preferred	Additional Guidance
		values	
	Requ	ired values	
Screen Pack Pressure	Practice O-P-06	End pressure no greater	
Build		than 25% over starting	
		pressure value	
Melt Flow Rate	ASTM – D1238		Record and Report
Density	ASTM – D792 or ASTM	<1 g/cc for control and test	
	1505		
Ash	ASTM – D5630		Record and Report
Volatiles/Moisture	ASTM – D6980	< 0.5%	
Bulk Density	ASTM – D1895	>480 kg/m ³	
DSC	ASTM – D3418	Primary Peak not to exceed 180C	Record primary and secondary peaks temp and J/g. Calculate the J/g delta from primary peak to secondary peak if present.
Calculated Weight %	Basic	< 10% PE Content	



Pellet Irregularity	Porosity, roughness,		Record, Report, and	
	grainy, gloss etc		Photograph	
Extrusion Process	Unusual sticking, fumes,		Record and Report	
Irregularity	odor or build-up			
	occurring at the feed			
	throat or die exit of the			
	extruder			
Optional value				
Pellet Color Variations	ASTM – D6290	Only for natural pellets	Can reveal	
or Inconsistencies			contamination before	
			later evaluation	





Path 1 and 2 – ASTM Part Evaluation

Property	Method	APR Guidance Preferred	Additional Guidance	
		values		
	Required values			
Met Flow Rate	ASTM – D1238		Record and Report	
Tensile Strength	ASTM – D638	No more than a 25%		
		decrease, control to test		
		sample.		
Elongation at Yield	ASTM – D638	No more than a 50%		
		decrease, control to test		
		sample		
Notched Izod	ASTM – D256	Control and test sample	Record and report break	
		should have same break	type (no break, partial,	
		type or show greater	hinge, complete) and	
		ductility.	values for the control and	
			test.	
Flexural Modulus	ASTM – D790	No more than a 25%		
		decrease, control to test		
		sample.		
Optional values				
ESCR	ASTM D1693		Record and Report –	
			Preferred not to exceed	
			25% failures to the control	
			for max. time reached.	



Path 1: Flow Diagram for "PP Rigid" that employ qualified (New resins, additives, coatings, layers, adhesives, labels or blends)





Path 2: Flow Diagram for "PP Rigid" Resin (Only an Option When Innovation is submitted as a blended pellet for Pre-Application)



12 of 13 ©2022 Association of Plastic Recyclers. All Rights Reserved



DOCUMENT VERSION HISTORY

Version	Publication Date	Revision notes
1	12-5-2019	Made minor clarifying changes, approved by OTC on 10/2/19
2	May 17, 2021	Added language clarifying need for pre-requisite testing
3	August 17, 2021	Changed MFR requirement for pellet and ASTM part testing to "Test and Report" in both Pathways 1 and 2; added expanded disclaimer language
4	June, 2022	Changes to ASTM evaluation criteria as per OTC
5	September 9, 2024	Changes to naming convention for Sortation protocols; Updated hyperlinks to match new website

